

GEN 2.4 Location indicators

The location indicators marked with an asterisk (*) cannot be used in the address component of AFS messages.

1. ENCODE	
Location	Indicator
AMBROLAURI	UGAM
BATUMI	UGSB
KUTAISI/KOPITNARI	UGKO
MESTIA	UGMS
NATAKHTARI	UGSA
TBILISI CAA	UGGU
TBILISI FIR	UGGG
TBILISI/TBILISI	UGTB
TELAVI	UGGT*

2. DECODE	
Indicator	Location
UGAM	AMBROLAURI
UGGG	TBILISI FIR
UGGT*	TELAVI
UGGU	TBILISI CAA
UGKO	KUTAISI/KOPITNARI
UGMS	MESTIA
UGSA	NATAKHTARI
UGSB	BATUMI
UGTB	TBILISI/TBILISI

PAGE INTENTIONALLY LEFT BLANK