

GEN 2.4 Location indicators

The location indicators marked with an asterisk (*) cannot be used in the address component of AFS messages.

| 1. ENCODE | |
|-------------------|------------------|
| Location | Indicator |
| AMBROLAURI | UGAM |
| BATUMI | UGSB |
| KUTAISI/KOPITNARI | UGKO |
| MESTIA | UGMS |
| NATAKHTARI | UGSA |
| TBILISI CAA | UGGU |
| TBILISI FIR | UGGG |
| TBILISI/TBILISI | UGTB |
| TELAVI | UGGT* |

| 2. DECODE | |
|------------------|-------------------|
| Indicator | Location |
| UGAM | AMBROLAURI |
| UGGG | TBILISI FIR |
| UGGT* | TELAVI |
| UGGU | TBILISI CAA |
| UGKO | KUTAISI/KOPITNARI |
| UGMS | MESTIA |
| UGSA | NATAKHTARI |
| UGSB | BATUMI |
| UGTB | TBILISI/TBILISI |

PAGE INTENTIONALLY LEFT BLANK