## STANDARD DEPARTURE ROUTES - INSTRUMENT (SID) RWY 31 (SOSED)

SID	ROUTING AND ALTITUDES	MIN. CLIMB GRAD.
	NEDEK ONE ALFA	
NEDEK 1A	After take–off climb on RWY heading to 700 FT, continue climb to 6000 FT turning RIGHT onto track 023° to intercept bearing 353° of LU NDB, therefrom on track 353° to NEDEK to be over NEDEK at 6000 FT or above.	
	SARPI ONE ALFA	
SARPI 1A	After take–off climb on RWY heading to 3500 FT, continue climb to FL 100 turning RIGHT onto track 126° to intercept bearing 216° of LU NDB, then turn RIGHT to LU, therefrom on track 242° to SARPI to be over SARPI at FL 100 or above.	
	SOSED ONE ALFA	
SOSED 1A	After take-off climb on RWY heading to 700 FT, continue climb to FL 90 turning RIGHT onto track 023° to intercept bearing 313° of LU NDB, therefrom on track 313° to SOSED to be over SOSED at FL 90 or above.	