

STANDARD DEPARTURE ROUTES – INSTRUMENT (SID) RWY 31 (SOSED)

SID	ROUTING AND ALTITUDES	MIN. CLIMB GRAD.
NEDEK 1A	<p>NEDEK ONE ALFA</p> <p>After take-off climb on RWY heading to 700 FT, continue climb to 6000 FT turning RIGHT onto track 023° to intercept bearing 353° of LU NDB, therefrom on track 353° to NEDEK to be over NEDEK at 6000 FT or above.</p>	
SARPI 1A	<p>SARPI ONE ALFA</p> <p>After take-off climb on RWY heading to 3500 FT, continue climb to FL 100 turning RIGHT onto track 126° to intercept bearing 216° of LU NDB, then turn RIGHT to LU, therefrom on track 242° to SARPI to be over SARPI at FL 100 or above.</p>	
SOSED 1A	<p>SOSED ONE ALFA</p> <p>After take-off climb on RWY heading to 700 FT, continue climb to FL 090 turning RIGHT onto track 023° to intercept bearing 313° of LU NDB, therefrom on track 313° to SOSED to be over SOSED at FL 090 or above.</p>	