

AERODROME CHART - ICAO

41° 36' 37" N
041° 35' 58" E

ELEV. 37'

TWR 118.6

BATUMI (UGSB)

RWY	DIRECTION	THR	BEARING STRENGTH
12	124°	41°37'01"N 041°35'20"E	PCN 35/F/B/X/T RWY, all TWY and apron
30	304°	41°36'08"N 041°36'42"E	

INS COORDINATES FOR AIRCRAFT STANDS					
POS.	COORDINATES		POS.	COORDINATES	
10	41°36'21.27''N 041°36'39.74''E		14A	41°36'25.04''N 041°36'31.63''E	
10A	41°36'19.79''N 041°36'41.44''E		15	41°36'25.07''N 041°36'32.19''E	
11	41°36'22.34''N 041°36'38.36''E		15A	41°36'25.49''N 041°36'32.26''E	
12	41°36'23.41''N 041°36'36.98''E		16	41°36'25.74''N 041°36'33.12''E	
13	41°36'24.48''N 041°36'35.60''E		16A	41°36'26.02''N 041°36'32.27''E	
14	41°36'24.39''N 041°36'31.26''E				

