

GEN 2.5 List of radio navigation aids

ID	Station Name	Aid	Purpose
BKU	BAKURIANI	DME	E
BT	ALI	NDB	E
BTM	BATUMI	DME	AE
DF	MUKHRANI	NDB	AE
GUD	GUDAURI	DME	E
IKO	KUTAISI/KOPITNARI	ILS/DME	A
IKS	KUTAISI/KOPITNARI	ILS/DME	A
ILU	BATUMI	ILS/DME	A
INA	TBILISI/TBILISI	ILS/DME	A
IVP	TBILISI/TBILISI	ILS/DME	A
KTS	KUTAISI	DVOR/DME	AE
LU	BATUMI	NDB	AE
PTI	POTI	DME	E
TBS	TBILISI	DVOR/DME	AE
TSN	TSNORI	DME	E

Station Name	Aid	ID	Purpose
ALI	NDB	BT	E
BAKURIANI	DME	BKU	E
BATUMI	DME	BTM	AE
BATUMI	ILS/DME	ILU	A
BATUMI	NDB	LU	AE
GUDAURI	DME	GUD	E
KUTAISI	DVOR/DME	KTS	AE
KUTAISI/KOPITNARI	ILS/DME	IKO	A
KUTAISI/KOPITNARI	ILS/DME	IKS	A
MUKHRANI	NDB	DF	AE
POTI	DME	PTI	E
TBILISI	DVOR/DME	TBS	AE
TBILISI/TBILISI	ILS/DME	INA	A
TBILISI/TBILISI	ILS/DME	IVP	A
TSNORI	DME	TSN	E

A = Aerodrome, E = En-route, AE = Both

PAGE INTENTIONALLY LEFT BLANK